




Kurzanleitung  
Quick Guide  
Guide rapide  
Snelle handleiding  
Guida rapida  
Szybki przewodnik

Краткое руководство  
Ghid rapid  
Stručný sprievodca  
Stručný průvodce  
Gyors útmutató  
Hızlı rehber





Nicht waschen / Do not wash / Ne pas laver / Niet wassen / Non lavare / Nie prać / Не стирать / Nu se spala / Neumývajte / Neumývejte / Ne mossuk / Yıkamayın



Nicht bleichen / Do not bleach / Ne pas blanchir / Niet bleken / Non candeggiare / Nie wybielać / Не отбелывать / Nu īnälbiti / Nebelit / Nebēlit / Ne fehérítsd / Ağartmayın



Nicht im Wäschetrockner trocknen / Do not tumble dry / Ne pas sécher en sèche-linge / Niet in de droger drogen / Non asciugare in asciugatrice / Nie suszyć w suszarce bębnowej / Не сушить в барабане / Nu se usucă cu tambur / Nesušiť v bublovej sušičke / Nesušiť v sušičce / Ne száritsuk száritógépben / Çamaşır makinesinde kurutmayın



Nicht bügeln / Do not iron / Ne pas repasser / Niet strijken / Non stirare / Nie prasować / Не гладить / Nu se calcă / Nežehliť / Nežehlit / Ne vasaljon / Ütü yapmayın



Nicht für die chemische Reinigung geeignet (Nicht trockenreinigen) / Not suitable for dry cleaning / Ne convient pas au nettoyage à sec / Niet geschikt voor stomerij / Non adatto al lavaggio a secco / Nie nadaje się do czyszczenia chemicznego / Не подходит для химчистки / Nu se curăță pe uscat / Nevhodné na chemické čistenie / Nevhodné pro chemické čištění / Száraz tisztításra nem alkalmas / Kuru temizleme için uygun değildir



24 h

